

OPERATOR'S MANUAL

BM-21

BEVELLING MACHINE



Unit 21 Empire Business Park, Enterprise Way, Burnley
Lancashire, BB12 6LT, UK

Phone: +44 1706 229490, Fax: +44 1706 830496

www.jeiuuk.com e-mail: sales@jeisolutions.co.uk

Contents

1. GENERAL INFORMATION	3
1.1. Application	3
1.2. Technical data.....	3
1.3. Equipment included	5
2. SAFETY PRECAUTIONS.....	5
3. STARTUP AND OPERATION	7
3.1. Adjusting bevel width and angle.....	7
3.2. Usage	9
3.3. Beveling pipes.....	11
3.4. Beveling larger pipes (only for optional equipment)	13
3.5. Replacing cutting inserts	13
3.6. Replacing milling head	15
4. WIRING DIAGRAM	16
5. SPARE AND WEARING PARTS.....	18
6. DECLARATION OF CONFORMITY	19
7. QUALITY CERTIFICATE.....	20
8. WARRANTY CARD.....	21




Read Operator's Manual before starting


1. GENERAL INFORMATION

1.1. Application

The BM-21 Beveling Machine is designed for milling edges of plates and pipes made of carbon steel. The machine allows for beveling sheet edges as well as pipe edges with diameters from 150 mm (6") to 300 mm (12") in 0–60° range with maximum bevel width of 21 mm (13/16"). When equipped with the optional guide available in separate order, it can also work on pipes with diameters above 300 mm (12"). The machine contains dampers allowing for comfortable operation, reducing unwanted vibrations.

1.2. Technical data





Voltage	~ 220–240 V, 50–60 Hz ~ 110–120 V, 50–60 Hz
Electric motor	Single-phase induction motor with run capacitor; 1100 W
Power	1600 W (for 50 Hz) 1800 W (for 60 Hz)
Rotational speed	2780–3340 rpm (at 230 V) 2740–3290 rpm (at 115 V)
Protection level	IP 20
Protection class	Class I
Milling speed	550 m/min (1800 ft/min, for 50 Hz) 650 m/min (2200 ft/min, for 60 Hz)
Maximum bevel width	$b \approx 21 \text{ mm}$ (13/16", Figure 1)
Bevel angle range	$0^\circ \leq \beta \leq 60^\circ$ (Figure 1)
Weight	Approx. 23 kg (51 lbs)




Figure 1. Bevel dimensions

1.3. Equipment included

The BM-21 Beveling Machine is supplied in a metal box with complete standard equipment. The included equipment consists of:

- beveling machine with a set of cutting inserts – 1 unit
- metal box – 1 unit
- 8 mm Allen key – 1 unit
- 6 mm Allen key – 1 unit
- 4 mm Allen key – 1 unit
- 12 mm flat key – 1 unit
- torx T15x100 screwdriver – 1 unit
- Operator's Manual – 1 unit

2. SAFETY PRECAUTIONS

1. Before starting, read this Operator's Manual and complete proper occupational safety and health training.
2. Machine must be used only in applications specified in Operator's Manual.
3. Machine must be complete and all parts must be genuine and fully operational.
4. Power supply specifications must conform to those specified on rating plate.
5. Power supply socket must be equipped with grounding pin.
6. Never carry machine by cord or yank it to disconnect plug from socket. It may cause power cord to break and result in electric shock.
7. Untrained bystanders must not be present near machine.
8. Before starting, check condition of machine and electrical installation, including power cord, plug, control panel components, and milling tools.
9. Keep machine dry. Exposing it to rain, snow, or frost is prohibited.
10. Keep work area well lit, clean, and free of obstacles.
11. Never use machine near flammable fluids or gases, nor in explosive environments.
12. Never use blunt or damaged tools.
13. Use only tools recommended by manufacturer and specified in Operator's Manual.
14. Mount cutting inserts and milling head securely. Remove adjusting keys and wrenches from work area before connecting plug to power socket.

15. If cutting edge of insert is worn out, rotate insert in socket by 90° or, if all edges are worn out, replace with new insert specified in Operator's Manual.
16. Before every use, inspect machine to ensure it is not damaged. Check whether any part is cracked or improperly fitted. Make sure to maintain proper conditions that may affect machine operation.
17. Always use safety goggles, hearing protection, gloves, and protective clothing during operation. Do not wear loose clothing.
18. Do not touch moving parts or metal chips formed during milling. Prevent objects from being caught in moving parts.
19. After every use, remove metal chips from machine, particularly from milling head. Never remove metal chips with bare hands.
20. Maintain machine and tools with care. Cover steel parts with thin grease layer to protect them against rust when not in use for a longer period.
21. Perform all maintenance work only with power cord unplugged from power socket.
22. Perform all repairs only in service center appointed by seller.
23. If machine falls on hard surface, from height, is wet, or has other damage that could affect technical state of machine, stop operation and immediately send machine to service center for inspection.



WARNING! Safety rules must be closely observed.


3. STARTUP AND OPERATION



WARNING! Read safety precautions before starting.

3.1. Adjusting bevel width and angle

Before starting, set required bevel width and angle. First, with power cord unplugged from power socket, set the milling head penetration to zero. To do this, loosen the lever (Figure 2) and rotate the adjusting knob to decrease the penetration of the milling head into the workpiece by setting the indication “0” on the width pitch.






Figure 2. Adjusting bevel width and angle

To change the angle of the bevel, use the supplied 6 mm Allen key to loosen two side bolts. Then, turn the guide in a way to set the required angle on the angle pitch and tighten the bolts afterward.

To adjust the bevel width, use the adjusting knob, proceeding as described before. The width pitch is only an estimate, because the bevel width varies with angle. For example, for the angle of 10° the maximum width “b” (Figure 1) is approximately equal 18 mm (11/16”), while the width pitch indicates 9 mm (6/16”). Increasing the penetration at this angle will distort the bevel. You can obtain the maximum bevel width ($b \approx 21$ mm, 13/16”) for the angle of 45° . The demanded bevel width for the

required angle must be determined experimentally by gradually increasing the milling head penetration into the workpiece.

3.2. Usage

After setting the bevel width and angle, plug the machine into the grounded power socket. Then, place the machine vertically on the right side of the workpiece as shown in Figure 3 in a way that the milling head does not touch the working edge.




Figure 3. Machine prepared for work on metal plates

Turn on the power, which will illuminate the power switch (Figure 4). Turn on the motor using the motor ON switch, press the guide to the plate, and slowly move the machine close to the edge. Bevel by sliding the machine to the left. Bevelling is performed according to the counter-rotation. The proper feed direction is shown in Figure 3. The direction of the milling head rotation is indicated on the motor disk under the milling head cover.




Figure 4. Control panel design

The feed rate will depend on the profile and composition of the workpiece. You can bevel the majority of steels capable of being welded in just one pass.

It is recommended that bevels wider than 12 mm (1/2") be accomplished in at least two or three passes. In this case you use less effort and the process takes less total time than for bevelling in single pass.

To obtain the maximum bevel width (21 mm, 13/16") in two passes, the first pass should be 14 mm wide (9/16"), whereas for three passes the first one should be 12 mm wide (1/2") and the second one 16 mm wide (5/8").

If the feed is too fast, the red overload lamp illuminates, indicating motor overload. Further load increasing triggers the safety circuit and shuts down the motor. In this case, move the tool away from the bevelled edge, toggle power switch to position "0", and after the red lamp turns off, turn on the power again. Operating with the maximum permitted load (flashing of the red lamp) is allowed, but the motor temperature must not exceed 85°C (185°F). This type of motor can work under high temperatures, but long-lasting overheating can permanently damage its windings. Therefore, after longer working under full load (maximum 1 hour), stop the motor to cool it down for 10–15 minutes. Do not cool down the motor by running it without load, because it will become heated even faster than when working with load.

Once the work is finished, press the motor OFF switch to stop the motor, and toggle the power switch to position "0" to turn off the power.

3.3. Beveling pipes

The guide with rollers supplied in the standard equipment allows for beveling pipes with diameters in 150–300 mm range (6–12”).

To prepare the machine for work on pipes, use the supplied 6 mm Allen key to unscrew two bolts that lock the guide (Figure 5). Then, take out the guide set, rotate it by 180° around the vertical axis, mount again, and secure with the bolts.




Figure 5. Preparing the machine for work on pipes

Use the supplied 8 mm Allen key and 12 mm flat key to unscrew the bolts that secure the rollers. Then, move rollers from the opening (Figure 6a) to slot (Figure 6b) by placing the T-nut into the slot.




Figure 6. Method of moving the rollers from opening to slot

Use the adjusting knob to set the indication “0” on the width pitch. Move the rollers away from each other and place the machine as shown in Figure 7, with the guide touching the pipe. Then, move the rollers symmetrically to touch the pipe, secure with the bolts in this position, and adjust the required bevel width and angle.




Figure 7. Machine prepared for work on smaller pipes (Ø150–300 mm, 6–12”)

3.4. Beveling larger pipes (only for optional equipment)

You can optionally order the guide for beveling larger pipes with diameters from 260 mm to 600 mm (10–24"). To prepare the machine for work on larger pipes, disassemble the guide set as shown in Figure 5. Use the supplied 4 mm Allen key to unscrew the standard guide and mount the guide for larger pipes (Figure 8), then screw in the bolts and mount the rollers as shown in Figure 6b.




Figure 8. Machine prepared for work on larges pipes (\varnothing 260–600 mm, 10–24")

3.5. Replacing cutting inserts

The machine is equipped with the uniform milling head that contains two insert rings, each holding five cutting inserts made of carbide, for a total of 10 inserts. The inserts can be replaced or rotated. Perform this work only with the power cord unplugged from power socket. To replace or rotate an insert, unscrew the lever (Figure 9), remove the pitch, and take out the milling head cover.




Figure 9. Dismantling milling head cover

Use the supplied screwdriver to unscrew the set screw (Figure 10), then remove the external insert, and clean the socket. Next, place the rotated insert again or replace with a new one if all four edges are worn out. To replace an insert from the internal ring, remove the external insert first.




Figure 10. Replacing cutting inserts

If the width of performed bevels is low, the cutting inserts wear only on one, internal corner. Then, the good action is to change the inserts between the rings (Figure 11), which extends the life of the inserts.




Figure 11. Changing cutting inserts between rings

3.6. Replacing milling head

To replace the milling head, remove its cover in the manner shown in Figure 9. Then, place a 32 mm flat key on the driving ring (Figure 12) to lock the spindle rotation, use the supplied 8 mm Allen key to unscrew the bolt, and remove the milling head. The 32 mm flat key is not included in the standard equipment.





Figure 12. Replacing milling head



BM-21

4. WIRING DIAGRAM



5. SPARE AND WEARING PARTS

Name	Number
Milling head (including mounting screws, screwdriver, and grease)	BM21-24
Cutting insert	BM21IS
Mounting screw for inserts	BM21-41
Screwdriver for mounting screws	BM21-67

6. DECLARATION OF CONFORMITY***EC Declaration of Conformity***

We

***JEI Group Ltd
Unit 21 Empire Business Park,
Enterprise Way, Burnley
Lancashire, BB12 6LT***

declare with full responsibility that product:

BM-21 BEVELLING MACHINE

which the declaration applies to is in accordance with the following standard:

- EN 50144-1

and satisfies safety regulations of the guidelines: 2006/95/EC and 2006/42/EC.



Burnley, 01 December 2017

David McFadden
Managing Director

7. QUALITY CERTIFICATE


Machine control card BM-21 BEVELLING MACHINE

Serial number

Electric test


Type of test	Result	Name of tester
Test with sinusoidal voltage (voltage 1000 V, frequency 50 Hz)	 Date
Resistance of the protective circuit Ω Signature

Quality control



Adjustments, inspections

Quality control



8. WARRANTY CARD

WARRANTY CARD No.....

..... in the name of Manufacturer warrants the BM-21 Bevelling Machine to be free of defects in material and workmanship under normal use for a period of 12 months from date of sale.

This warranty does not cover cutting inserts, damage or wear that arise from misuse, accident, tempering or any other causes not related to defects in workmanship or material.

Date of production

Serial number

Date of sale

Signature of seller.....

1.06 / 21 November 2016

***WE RESERVE THE RIGHT TO MAKE CORRECTIONS
AND MODIFICATIONS IN THIS MANUAL WITHOUT PRIOR NOTICE***

