

OPERATOR'S MANUAL

WELDING CARRIAGE

LIZARD



Unit 21 Empire Business Park, Enterprise Way, Burnley, BB12 6LT

Phone: 01706 229490

www.steelbeast.co.uk e-mail: sales@steelbeast.co.uk

Contents

1. GENERAL INFORMATION	3
1.1. Application	3
1.2. Technical data.....	4
1.3. Equipment included	5
1.4. Dimensions	6
1.5. Design	7
2. SAFETY PRECAUTIONS.....	8
3. STARTUP AND OPERATION	10
3.1. Preparing	10
3.2. Connecting to the welding circuits.....	12
3.3. Positioning at the work area	14
3.4. Starting	15
3.5. Programming	15
3.6. Welding procedure.....	17
3.7. Operating.....	18
3.8. Using oscillator (option).....	19
3.9. Troubleshooting	22
4. MAINTENANCE	23
5. ACCESSORIES	24
5.1. Oscillator.....	24
5.2. Torch holders, clamps, and rods	26
5.3. Torch extension arm	28
5.4. Guide arms	29
5.5. Dual torch mount.....	34
5.6. Flexible guide set	35
5.7. Guide adjustment tool	37
5.8. 76 mm cross slide	38
5.9. Display protection shield	39
5.10. Fall arrester.....	39
5.11. Stainless steel wheels.....	40
6. DECLARATION OF CONFORMITY	41
7. ENVIRONMENTAL PROTECTION	42
8. WARRANTY CARD.....	43

1. GENERAL INFORMATION

1.1. Application

The LIZARD is a welding carriage designed to make butt and fillet welds that are continuous or stitch. The carriage allows MIG/MAG torches and is clamped with permanent magnets.


Accessories allow welding with oscillation, using torches with a larger diameter, and using two torches at the same time. They also allow the carriage to move along outside edges, lap joints and templates, walls that are low or have holes, and on ceilings, pipes, and tanks.

The machine is designed for use by a professional operator only.



1.2. Technical data

Voltage		1~ 115–230 V, 50–60 Hz 1~ 42 V, 50–60 Hz
Power		25 W
Welding position (according to EN ISO 6947 and AWS/ASME)	Horizontal	PA/1F/1G PB/2F PC/2G PD/4F PE/4G
	Vertical	PF/3F/3G (with an optional oscillator) PG/3F/3G (with an optional oscillator)
Minimum path curve radius		1500 mm (59 1/16")
Torch type		MIG/MAG
Torch diameter		16–22 mm (5/8–55/64")
Maximum torch reach		80 mm (3 5/32")
Maximum allowed cable weight	Horizontal work	12 kg (27 lbs)
	Vertical work	8 kg (18 lbs)
Minimum workpiece thickness		5 mm (13/64")
Ground clearance		5 mm (13/64")
Horizontal pulling force		220 N
Vertical pulling force		150 N
Cross slide adjustment range		0–35 mm (0–1 3/8") (up-down, left-right)
Guide arm adjustment range		0–120 mm (0–4 23/32")
Horizontal speed		0–130 cm/min (0–51 3/16 in/min)
Vertical speed		0–120 cm/min (0–47 1/4 in/min)
Noise level		Less than 70 dB
Weight		14 kg (31 lbs)
Protection class		I
Protection level		IP 20
Required ambient temperature during operation		0–50 °C (32–122 °F)
Required ambient temperature during storage		-10–70 °C (14–158 °F)
Maximum allowed ambient humidity (non-condensing)		80 %


1.3. Equipment included



1	Carriage	1 unit
2	4 mm hex wrench	1 unit
3	Cable anchor	1 unit
4	Short rod torch holder with clamp	1 unit
5	6.5 m (21 ft) arc ignition cable	1 unit
6	Plastic box	1 unit
–	Operator's manual	1 unit

1.4. Dimensions

1.5. Design



2. SAFETY PRECAUTIONS

1. Before using it, read this operator's manual and complete training in occupational safety and health.
2. Use only in applications specified in this operator's manual.
3. Make sure that the carriage has all parts, and they are genuine and not damaged.
4. Make sure that the specifications of the power source are the same as those specified on the rating plate.
5. Connect the carriage to a correctly grounded power source.
6. Do not carry the carriage with cables, and do not pull them. This can cause damage and electrical shock.
7. Keep untrained bystanders away from the carriage.
8. Before each use, ensure the correct condition of the carriage, power source, cables, plugs, sockets, control panel, and wheels.
9. Before each use, make sure that no part is cracked or loose. Make sure to maintain correct conditions that can have an effect on the operation of the carriage.
10. Keep the carriage dry. Do not expose the carriage to rain, snow, or frost.
11. Keep the work area well lit, clean, and free of obstacles.
12. Do not use near flammable materials or in explosive environments.
13. Make sure that the rubber of the wheels is clean and not damaged.
14. Do not remove the cover of the wheels.
15. Remove objects attracted to the chassis by the magnet.
16. Transport and position the carriage by using the carrying handle and only after you set the magnet lever to 'O'.
17. Put the carriage so that four wheels are on the surface. Make sure that no contact is between the surface and chassis.
18. Do not stay below the carriage that is put at heights.
19. Connect the cables only after you set the power switch to 'O'.
20. Keep the sockets clean. Do not use high pressure during cleaning.
21. Install only MIG/MAG torches whose diameter is the same as the diameter of the torch holder.
22. Do not put the torch more than 80 mm (3 5/32") outward from the left or right side of the carriage.

23. Keep the torch cables away from the surface. Hang them to decrease the load applied on the carriage. Use only cables whose weight is not more than 12 kg (27 lbs) for horizontal work and 8 kg (18 lbs) for vertical work.
24. Do not work on curves with convex or concave radius less than 1500 mm (59 1/16").
25. At heights, use a fall arrester not to let the carriage fall.
26. Use eye protection (helmet, shield, and screen), ear protection, gloves, and protective clothing. The clothing must not be loose.
27. Do not stop the carriage by hand. To stop, set the travel direction switch to 'O'.
28. Do the maintenance only after you unplug the carriage from the power source.
29. Repair only in a service center appointed by the seller.
30. If the carriage falls, is wet, or has any damage, stop the work and immediately send the carriage to the service center for check and repair.
31. Do not leave the carriage unattended during work.
32. If you are not going to use the carriage, remove it from the work area and keep in a safe and dry place.

3. STARTUP AND OPERATION

3.1. Preparing

Use the carrying handle to transport the carriage to the worksite. Set to 'O' all switches (power, travel direction, and arc ignition switch) and the magnet lever.




Fig. 1. View from the back

You can change the torch adjustment range to the right by 22 mm (55/64"). Use 4mm hex wrench to detach the slide arm. Then, install it with four screws as shown in fig. 2.




Fig. 2. Changing the adjustment range to the right

You can change the torch adjustment range upward by 22 mm (55/64"). Use 4 mm hex wrench to detach the cross slide. Then, install it with four screws as shown in fig. 3.




Fig. 3. Changing the adjustment range upward

Use the power cord to connect the carriage to the power source. Then, put the torch into the torch holder and tighten with the knob. Put the torch cables into the cable anchor and tighten with the knobs.

3.2. Connecting to the welding circuits

Before connecting, read the operator's manual of the welding device and make sure that it provides such an option. Connect the arc ignition cable only to the arc ignition control contacts in the welding device remote control socket. Make sure that the welding cycle control of the welding device is set to 2-stroke. If you set it to 4-stroke, arc ignition control will work incorrectly.



Do not connect to sockets other than the arc ignition remote control socket, specified by the manufacturer of the welding device. Incorrect connection of the arc ignition cable to the welding device may result in permanent damage to the carriage!

The carriage can be connected to a welding device (welding machine, wire feeder). Make sure that the device provides a start-stop signal (see the operator's manual provided by the manufacturer).

The carriage can control two torches by using the arc ignition cable plugged into the arc ignition socket. To do this, refer to the diagram from fig. 4 and connect one blue-jacketed wire to one terminal of the welding circuit. Then, connect the other blue-jacketed wire to the other terminal of the same circuit. To control the second torch, connect the green-jacketed wires to the terminals of the second welding circuit.




Fig. 4. Connecting the arc ignition cable to welding circuits

Make sure that the arc ignition cable is connected correctly. To do this, turn on the power of the carriage, and then set the arc ignition switch to TEST. This should enable the arc for a while.

3.3. Positioning at the work area

Put the guide arms so that the carriage is in constant contact with the workpiece. You can set them by a constant step (interval adjustment), or continuously after you swap them (continuous adjustment). To set them correctly when the carriage moves to the left, use the 4 mm hex wrench to loosen the screws that secure the right guide arm. Next, move out the right arm about 10 mm (25/64") or one groove more than the left arm (Fig. 5), and then tighten the screws again.




Fig. 5. Correct positioning of the guide arms

To put the carriage closer to the workpiece, use the 4 mm hex wrench to remove the roller assemblies. Next, install them at the other end of the guide arms, and then swap the guide arms (fig. 5).

Switch the magnet lever from left ('O') to right ('I'). This will change the clamping force from minimum to maximum.

Loosen the levers to adjust the position and angle of the torch. Use two knobs at the cross slide to precisely set the torch position.

At heights, attach a fall arrester (not included) to a lug (fig. 5) to prevent fall of the carriage. This will avoid possible injury to the operator in case the carriage loses the clamping. Do not stay below the carriage that is put at heights!

3.4. Starting

Plug the power cord into the power source and set the power switch to 'I' to turn on the carriage. Then, an initial screen with the current firmware number shows. If an oscillator is connected to the oscillation socket, `Oscillator found` shows. After the control system is loaded, the main menu from Fig. 6 shows.




Fig. 6. View of the main menu

Press and hold the knob F1 for about 3 seconds to go into the configuration menu and set the welding parameters.

3.5. Programming

The carriage allows you to define up to 40 welding programs. After you go to the configuration menu, continue as described in Fig. 7.

Value of parameter. Rotate the knob F2 to change the value by the higher step shown in Tab. 1. Press and rotate the knob F2 to change the value by the lower step.

Name of parameter. Rotate the knob F1 to change among parameters shown in Tab. 1.




Fig. 7. Configuration menu

Parameter	Value	Description
Carriage speed	0–130 cm/min 0–52 in/min [step: 1 or 0.1]	Speed of the carriage.
Weld length	1–250 cm 1–100 in [step: 1 or 0.1]	Length of a single weld.
Skip	0–100 cm 0–40 in [step: 1 or 0.1]	Space between welds. If set to zero, crater fill' and 'back weld' are reset and the carriage works in the continuous welding mode.
Crater fill	0–3 s [step: 0.1]	Time of filling the crater. Inactive if 'skip' set to zero, which is indicated by the (!) sign.
Current lowering	YES NO	Function of the welding source to lower the current of the arc while filling the crater. Time of filling the crater must be set higher or equal to the time of the current lowering that is set at the welding source.
Backweld	0–2 cm 0–2 in [step: 0.1]	Length of the back weld. Shorter or equal to 'weld length'. Inactive if 'skip' set to zero, which is indicated by the (!) sign.
Total length	0–1000 cm 0–400 in infinity [step: 10 or 1]	Longer or equal to the sum of 'weld length' and 'skip'. If set to infinity, the program executes until you stop the carriage with the travel switch.
Unit	cm in	Unit used in the menu.
Save setup	1–40	Pressing knob F2 saves the current configuration to the indicated program number.
Load setup	1–40	Pressing knob F2 loads the configuration from the indicated program number.
Language	ENGLISH POLISH SPANISH FRENCH PORTUGUESE TURKISH GERMAN RUSSIAN	Language of the menu.

Tab. 1. Settings available in basic version of the carriage

To change the language of the menu, go to **Language** setting by rotating the knob F1 to the right, and then rotate the knob F2 to choose among the available languages. After the rest of the parameters from Tab. 1 is set, go to **Save setup** and choose a program number by rotating the knob F2. Then, press the knob to save the current values to this number. The message **Done** shows for a short time. To load a previously saved program, continue as described, but from **Load setup** setting. To go back to the main menu (Fig. 6), press the knob F1 and hold it for 3 seconds. If you do not save the chosen parameters, they will be active only until you change the current program number in the main menu.

3.6. Welding procedure

Fig. 8 shows a graphic description of the welding procedure that starts with the speed value shown in the main menu when you select a travel direction. The first stage is making the weld, and then the carriage fills the crater (stage 2) for the chosen time. Next, the carriage does the back weld (stage 3) and then moves to the start of the next weld (stage 4). This procedure is repeated until the carriage reaches the value of the total length.




Fig. 8. Visualization of the welding procedure according to parameters from Tab. 1

3.7. Operating

To control the torch through the carriage, set the arc ignition switch to 'I'.



If the arc ignition switch is set to 'I', the torch starts welding immediately after you select a travel direction.

With **Ready** mode shown on the main menu (Fig. 6), you can press and rotate the knob F2 to change the current program **Setup #1**. You can also use the speed knob to change the current welding speed. Rotate the knob to the right to increase the speed by the step of 0.1. Rotate to the left to decrease the speed by the step of 0.1.


Use the travel direction switch to select the direction of travel. Then, the carriage starts moving according to the chosen program parameters. The current operating mode shows on the display while the program continues. You can change the carriage speed during work with the speed knob. The new speed will be saved only if you do not change the current program in the meantime.

The carriage stops after it reaches the total length and **Job's done** message shows on the display. Then, set the travel direction switch to 'O' to go into the main menu. After the work is finished, use the power switch to turn off the carriage. Then, unplug the carriage from the power source.


3.8. Using oscillator (option)

3.8.1. Installation

Install the oscillator in the shown sequence.



- Remove the torch holder (1).
- Use the 4 mm hex wrench to remove the screws (2) and slide arm (3).
- Remove the cap (4).



- Attach the arm (5) to the oscillator (6).
- Use two screws M5x20 (7) to attach the oscillator (6) to the bracket (8).
- Use two screws M5x16 (9) to connect the bracket (8) to the cross slide (10).
- Put the oscillator plug (11) into the oscillation socket (12).
- Attach the torch holder (13) to the oscillator arm (5).

3.8.2. Welding with oscillation

After you connect the oscillator to the welding carriage, several new settings will show in the menu (Tab. 2). Welding with oscillation is done in the standard manner, but the weld forms a shape similar to the shape shown in Fig. 9 instead of the straight line from Fig. 8.

Parameter	Value	Description
Osc. amplitude	0–100% [step: 10% or 1%]	Relative amplitude of the oscillation.
Osc. speed	0–100% [step: 10% or 1%]	Relative speed of the oscillation. The higher the speed, the shorter the oscillation period.
Osc. delay 1	0–5 s [step: 1 or 0.1]	Dwell time in the top position of the oscillation.
Osc. delay 2	0–5 s [step: 1 or 0.1]	Dwell time in the bottom position of the oscillation.
Dwell times lock	YES NO	With YES, you cannot change dwell times during welding.

Tab. 2. Additional settings available with connected oscillator




Fig. 9. Graphic description of the oscillation parameters from Tab. 2

3.8.3. Operating

The carriage with connected oscillator is operated similarly to operating without the oscillator. During welding with the oscillator, the menu from Fig. 10 shows on the display.




Fig. 10. Menu shown during welding with the oscillator

If you set Dwell times lock to YES, nothing happens when you press the knob F1 or F2 during work. If you set the parameter to NO, the delay parameters show on the display and you can adjust them online (Fig. 11).




Fig. 11. Menu for changing the oscillator dwell times

3.9. Troubleshooting

Problem	Cause	Solution
Dark display after powering.	Malfunction of the power cord, power switch, power supply, or controller.	Contact service center for check and repair.
Errors on the display. Values cannot be read.	Malfunction of the display or power supply unit.	Contact service center for check and repair.
*** FATAL ERROR *** FRONT limit switch activated	Carriage reached an obstacle at the front.	Remove the obstacle that blocks the carriage or choose the opposite travel direction.
*** FATAL ERROR *** REAR limit switch activated	Carriage reached an obstacle at the rear.	Remove the obstacle that blocks the carriage or choose the opposite travel direction.
*** FATAL ERROR *** Travel switch incorrect signal	Too fast switching between left and right travel direction.	Set the travel direction switch to 'O'.
Set travel switch to zero	Travel direction switch not set to 'O' when powering.	Set the travel direction switch to 'O'.
	Shown during travel indicates a malfunction.	Contact service center for check and repair.

4. MAINTENANCE

Each day:

1. Clean the chassis and wheels.
2. Clean the rollers of the guide arms. Make sure that the rollers turn freely.
3. Clean the torch nozzle and replace it if damaged.


Each month:

1. Make sure that the knobs and the switches work as intended. Replace if they are loose or damaged.
2. Examine cables and cords and replace them if damaged.
3. Tighten screws if loose.

5. ACCESSORIES

5.1. Oscillator


Allows welding with oscillation. It can be installed vertically or horizontally.





Part number:
ZSP-0477-10-00-00-0






Oscillation type	Pendulum (maximum 11°)
Oscillation amplitude at r=150 mm (5 29/32")	1–30 mm (1–100%)
Oscillation speed at oscillation amplitude of 10 mm (25/64") and zero dwell time on ends	7–164 cycles/min (1–100%)
Dwell time on ends	0–5 s
Maximum torque	5 Nm (3.7 lb-ft)
Power	12 W
Weight	2.6 kg (5.7 lbs)







To get the correct shape of oscillation, make sure that the axis of the oscillator's output shaft crosses with the axis of the torch.






5.2. Torch holders, clamps, and rods

Short rod torch holder with clamp 16–22 mm	
	Part number: UCW-0754-07-00-00-0
Quick-release short rod torch holder with clip 16–22 mm	
	Part number: UCW-0523-84-00-00-0
Short rod torch holder with clip 16–22 mm	
	Part number: UCW-0476-27-00-00-0
Short low rod torch holder with clip 16–22 mm	
	Part number: UCW-0476-06-00-00-0
Long rod torch holder with clamp 16–22 mm	
	Part number: UCW-0752-07-00-00-0

Long rod torch holder with clip 16–22 mm	
	Part number: UCW-0466-22-00-00-0
Torch clamp 16–22 mm	
	Part number: ZRZ-0752-07-01-00-0
Torch clip 16–22 mm	
	Part number: ZCS-0476-06-01-00-0
Torch clamp 22–35 mm	
	Part number: ZRZ-0466-19-00-00-0
Short rod	
	Part number: WLK-0476-20-01-00-0
Long rod	
	Part number: WLK-0466-04-10-00-0

5.3. Torch extension arm

Increases the reach of the torch. Use the 4 mm hex wrench to remove the M5x10 screws that attach to the cross slide. Next, use the same screws to attach the cross slide at the end of the arm as shown in the figure. Then, use M5x16 screws to attach the arm to the carriage.




5.4. Guide arms

5.4.1. Edge following guide arms

Allow guiding the carriage along the outside edges. Use the 4 mm hex wrench to remove the standard guide arms and install the new guide arms.


Part number (2 units):
PRW-0476-21-00-00-1



5.4.2. Adjustable guide arms

Allow guiding the carriage along lap joints and templates. Use the 4 mm hex wrench to remove the standard guide arms and install the new guide arms.



Part number (2 units):
PRW-0476-22-00-00-1



5.4.3. Magnet guide arms

Allow guiding the carriage on ceilings. Use the 4 mm hex wrench to remove the standard guide arms and install the new guide arms.


Part number (2 units):
PRW-0476-52-00-00-1




5.4.4. Low guide arms

Allow guiding the carriage along low walls. Use the 4 mm hex wrench to remove the standard guide arms and install the new guide arms.

Part number (2 units):
PRW-0476-54-00-00-1






To put the carriage closer to the workpiece, use the 4 mm hex wrench to remove the roller assemblies. Next, install them at the other end of the guide arms, and then swap the guide arms.



5.4.5. High guide arms

Allow guiding the carriage along walls that have holes. Use the 4 mm hex wrench to remove the standard guide arms and install the new guide arms.



Part number (2 units):
PRW-0476-55-00-00-1



5.5. Dual torch mount

Allows using a second torch. Use the 5 mm hex wrench to remove the M6x16 screws that attach to the carrying handle. Next, use the same screws to attach the mount to the carriage.

Part number:
PDT-0466-40-00-00-0



5.6. Flexible guide set

Allows guiding the carriage on planes along a straight line, and on pipes and tanks. A single flexible guide is 1.85 m (6 ft) long. Its minimum curve radius is 1 m (3.3 ft).


Holding force on a 5 mm (13/64") thick surface	Temperature
100% (90 N)	20°C (68°F)
75% (68 N)	80°C (176°F)
50% (45 N)	120°C(248°F)

Connect two guides with the 3 mm hex wrench and M5x16 screws to form a butt or lap joint. Next, use the 4 mm hex wrench to remove the standard guide arms and install the new guide arms.

Flexible guide (1 unit):
PRW-0466-50-01-01-0



Butt joint


Lap joint



Magnet block set:
BLO-0466-68-00-00-0
(includes: 10 magnet blocks
and 22 screws M5x16)

Guide arms (2 units):
PRW-0476-50-01-00-1







5.7. Guide adjustment tool

Allows the guide to be put parallel to an outside edge or a groove.

Part number:
UST-0466-53-00-00-0




Attach the magnets to the guide and put the guide on the workpiece along the direction of welding. Loosen the levers and put the tool onto the first magnet, resting the side of the pilot pin on an outside edge or putting the tip of the pilot pin in a groove. Then, lock the levers in this position and pull the further part of the guide off the workpiece (1). Next, start moving the tool along the guide (2) to clamp the successive magnets to the workpiece.




5.8. 76 mm cross slide

Increases the up-down or left-right adjustment range from 0–35 mm (0–1 3/8") to 0–76 mm (0–2 63/64").

Part number:
ZSP-0466-46-00-00-1




Use the 4 mm hex wrench to remove the standard cross slide and install the new cross slide.



5.9. Display protection shield


Protects the display from dirt. Use the 2.5 mm hex wrench to remove the top screws of the panel and use them to attach the shield.



5.10. Fall arrester

Protects the carriage from falling. The length of the line is 10 m (33 ft).


Part number:
URZ-000001




5.11. Stainless steel wheels

Allow working in horizontal position on a preheated plate.

Part number (1 unit):
KOL-0476-57-00-00-0



As shown in the figure, use the 2.5 mm hex wrench to remove the cover and use the 4 mm hex wrench to remove four wheels. Install in reverse sequence.



6. DECLARATION OF CONFORMITY

Declaration of conformity

**JEI Drilling & Cutting Solutions Ltd
Unit 21 Empire Business Park
Enterprise Way, Burnley, BB12 6LT**

We declare with full responsibility that:

LIZARD WELDING CARRIAGE

is manufactured in accordance with the following standards:

- EN ISO 12100: 2010
- EN 60204-1: 2018
- EN IEC 60974-10: 2021

and satisfies regulations of the guidelines: 2014/30/EU, 2006/42/EC, 2011/65/EU.

Person authorized to compile the technical file:

David McFadden, JEI Drilling & Cutting, Burnley, Lancashire



Burnley, 23 October 2024

David McFadden
Managing Director

7. ENVIRONMENTAL PROTECTION



In accordance with the European Directive 2012/19/EU, this device is marked with the symbol of the crossed-out waste bin. This marking means that the equipment must not be disposed of with other household waste after the service life. The user must return the product to a collection point for used electrical and electronic equipment. The collectors of used equipment, including local collection points, shops and municipal units create an appropriate system for returning such equipment. Correct handling of used electrical and electronic equipment helps in avoiding damage to health and the environment, which may result from the presence of dangerous components and incorrect storage and processing of such equipment.

8. WARRANTY CARD**WARRANTY CARD No.....**

..... in the name of Manufacturer warrants the machine to be free of defects in material and workmanship under normal use for a period of 3 years (36 months) from the date of sale, except electronic parts which are covered with 2 years (24 months) warranty from date of sale and except batteries (if applicable) which are covered with 2 years (24 months) warranty from their manufacturing date.

This warranty does not cover tools and accessories as well as damage or wear that arise from misuse, accident, tempering, or any other causes not related to defects in workmanship or material.

Serial number

Date of sale

Signature and stamp of the seller

0.08 / 23 October 2024

WE RESERVE THE RIGHT TO MAKE CHANGES IN THIS MANUAL WITHOUT NOTICE